

SK-T26 Tool

Combination CLoc® T26 and T98-1 Tool (For all CLoc® and Camloc® Fasteners)



T26 - Installation of CLoc® or Camloc® R4G Snap Ring Retainers – Remove cap and taper insert.

Slide R4G Retainer onto insert towards the large end.



Push R4G Retainer onto grommet (Install grommets-retainers then install studs with 4P3 Pliers).

T98-1 - Installation of CLoc® or Camloc® 2000 Series Retainers (2600-LW and 27S5-1). Place retainer onto base of stud (cup); simply press retainer until seated.

